

HERA_Imaging_Demo

June 14, 2018

1 HERA Imaging Demo

CHAMP Bootcamp June 14, 2018 St. John's College, Sante Fe, NM

This notebook will guide you along the general steps needed to image HERA data with the CASA software. Because we spent this morning working with CASA on VLA data, it is assumed you have some familiarity with imaging and the CLEAN deconvolution algorithm.

This notebook is *not* meant to be run interactively, and only contains instructions on how to use CASA **interactively from your command line**.

Given that, all code in this notebook is meant to be run either from the bash shell (lines starting with \$) or from a CASA session (lines starting with >>>)

2 A : Start with the un-calibrated data

To begin, we will use the un-calibrated data from the beginning of our lesson on calibration.

Start with the data/zen.2458116.24482.xx.HH.uv0CRU file.

3 1) Convert Miriad file to Measurement Set file

From the command line, you should first run

```
$ miriad_to_uvfits.py filename
```

where filename is the path to the Miriad file (recall Miriad files are actually directories!). This takes your miriad file and turns it into a UVFITS file (with .uvfits file extension), and comes from the pyuvdata software.

Next run

```
$ casa -c "importuvfits(filename.uvfits, filename.ms)"
```

which should take your UVFITS file and turn it into a Measurement Set. If both of these commands worked, we are done! We now have a file that we can image with CASA.

4 2) Enter a CASA sessions and run listobs on the MS file

You can enter a casa session by just typing into your command line

```
$ casa
```

which will enter you into a Python-looking session (and it is Python!) but it has some special pre-loaded modules that are specific to the CASA software.

One of these is the `listobs` function, which will give you a summary of the observation. Try running that on your measurement set and looking at your CASA logger for the output.

Can you answer the following questions:

When / where was this data observed?

How many antennas were used in taking this data?

At which frequencies were the data observed?

At what sky position was the array pointed during the observation?

5 3) Make a “dirty” image of the data

A dirty image is an image that has not been *deconvolved*, that is to say that the effects of incomplete uv-sampling distorts the image from the underlying “true” sky signal. That being the case, making and looking at dirty images is good way to get a “quick-look” at the data and diagnose possible problems.

To make a dirty image we will use the CASA `clean` function you used before, but this time we will set `niter=0`. This will mean that it will fourier transform the data to create an image, but it won’t attempt to deconvolve (or CLEAN) the image.

```
>>> clean(visname, imagename, niter=0, mode='mfs', cell='400arcsec',  
imsize=512, spw='0:100~924', interactive=False)
```

Let’s step through each of these parameters:

`visname` is a string of the MS filename.

`imagename` is a string for the output image. Something like `imagename = visname + 'nocal'` should work.

`niter=0` means it **will not** attempt to deconvolve the data (which is what we want for now!)

`mode='mfs'` means we are making a *Multi-Frequency Synthesis* image, which is just fancy jargon for making a single image using data from all frequencies. Question: what imaging benefit might this give us?

`cell='400arcsec'` this means that the image will have pixels that are 400 arcseconds in size.

`imsize=512` this means that the image will contain 512 cells on each side, to make a 512 x 512 image.

`spw='0:100~924'` means it will use the zeroth spectral window (only one exists anyways) and take channels 100 to 924. We ignore the first and last 100 channels because they are almost always subnominal.

`interactive=False` this means we won’t do an interactive deconvolution, but this doesn’t matter because we won’t be deconvolving anyways (hence the name “dirty” image).

Once that finished open the CASA viewer to look at the image via

```
>>> viewer
```

What does the image look like? Can you make any sense of why it might look the way it does? What does the PSF look like?

6 B : Now repeat 1) - 3) with the calibrated data

Use `data/zen.2458116.24482.xx.HH.uvOCR` file.

How does this dirty image compare to the un-calibrated data? Did you expect this to look different?

7 4) Use `clean` to deconvolve the image

Before we were making dirty images, which if you recall, means that we were not deconvolving the image. That is to say, point sources in the image are spreading their flux throughout the image in a way governed by the point spread function (PSF). Deconvolution is an attempt to correct for this. There are a few algorithms to do this, but we will stick to the CLEAN algorithm implemented in CASA's `clean` function.

We already did this interactively in the Interferometry lesson. If you recall, you perform an interactive clean by specifying the argument

```
>>> clean(..., interactive=True)
```

If you'd like to perform a non-interactive deconvolution (i.e. a one-shot attempt), you can do this by setting `interactive=False` and specifying parameters like `niter` and `threshold` to tell CLEAN when to stop the deconvolution.

You can also specify a mask to tell CLEAN where to put model point sources (similar to making source boxes in an interactive CLEAN). The mask parameter takes the following form: `mask = circle([01h43m00s, -30d48m0s], 32000arcsec)` where the first two numbers tell where to center the circular mask in RA and Dec, and the third number is the size of the mask in arcseconds.

Note: if you use a mask, don't use the RA Dec values shown here: figure out what the appropriate coordinates should be given your previous dirty image!

After making and inspecting the image, try to answer the following questions:

How did the calibrated image change relative to the un-calibrated image? Did you expect this?

How many sources can you see in your image?

What is the peak flux of the brightest source in the field?

What is the rough RMS noise level of the image?

Congrats! You've made it to the end of the demo. By now you should have been able to make images from both un-calibrated and calibrated data! Hopefully this demonstrates the importance of calibration on all of the science that we do with the HERA instrument: good calibration is of utmost importance to yield science-quality data that we can then use to learn something about when and how the Epoch of Reionization took place.

In []: